





Pro-lite Goal

CONTENTS:



WARNINGS

- To be assembled & dismantled by an adult.
- To be used on a flat surface.
- Check the frame assembly is securely located before use.
- Ensure frame is securely pegged to ground before use.
- Do not leave outdoors in adverse weather conditions.
- Do not climb or hang from the structure.
- Check regularly for wear and tear. Discontinue use if any breakage is found. Failure to do this may result in injury.
- Keep away from fire.
- Keep away from heat sources.

THIS PRODUCT IS NOT SUITABLE FOR CHILDREN UNDER 3 YEARS DUE TO SMALL PARTS

Please retain this leaflet for reference to the manufacturer

Carefully made in China to European Safety Standard




DISTRIBUTED BY



MV SPORTS & LEISURE LTD
 35 Tameside Drive • Castle Bromwich
 Birmingham • B35 7AG • UK
 Email: info@mvsports.com
 www.mvsports.com

NOTE: WHEN JOINING TUBES TO CONNECTORS ALWAYS ENSURE THAT THE HOLES IN THE TUBES ALIGN PROPERLY WITH THE HOLES IN THE CONNECTORS BEFORE SECURING WITH TUBE FASTENERS.

1. Connect the frame tubes with letters together, as illustrated.
2. Apply tube fasteners (5) to each tube connection point, as illustrated. **NOTE: Fasteners lock after one quarter turn.**
3. Fit the plugs (8) into the bottom front elbow joints




Please ensure tube fasteners are only turned a quarter turn.

CUSTOMER HELPLINE


We make every effort to ensure that this product reaches you in satisfactory condition. However if you have any queries, need assistance, or find this product defective, please call our Customer Helpline:

0870 8404255 (UK ONLY)



6. Apply Kickmaster sticker before attaching the net to the frame.




7. Spread the net over the goal assembly and fasten in place using the net securing clips (6).



4. Join the net support tubes (1) in two pairs, using the net support tube connectors (4), as illustrated.



5. Fit each net support tube assembly by inserting one end into the hole in the elbow on the back cross bar. Carefully bend the tube towards the top cross bar and insert into the hole in the elbow. Make sure that the tube is pushed fully home into the elbows.



**Suggested
pegging points**

Securing Frame

Fix the frame to the ground using 4 pegs (7). Position around the frame base as illustrated. Secure pegs using a mallet.

CAUTION: Check regularly that pegs are secure. Loose pegs may cause injury. Care should be taken when using a mallet as misuse may cause injury.

CAUTION: When assembled the goal is under tension. Extreme care must be taken when disassembling. Check frame regularly to ensure tube frame toggles and net ties are secure.