


**3-IN-1 SWING - M008600**  
**TODDLER SWING AGED 6 TO 36 MONTHS**  
**JUNIOR SWING AGED 3 TO 10 YEARS**

## SAFETY GUIDELINES

### Warnings


**Only for domestic use.** This product has not been designed for commercial use in play centers, nurseries etc.  
**Only suitable for outdoor use.**  
**Toddler swing:** For children 6 - 36 months 20kg max.  
**Junior swing:** For children 3 - 10 years 45kg max.  
**Only one child per seat.**  
**The Harness must be securely fastened at all times during use in Toddler Seat with T-Bar configuration and Toddler Seat without T-Bar configuration**  
**Do not lean or push on the T-Bar**  
 The flat swing seat does not have a back or seat belt. It is not suitable for children under 3 years as they may not be able to balance themselves. For children under 3 years, please use the baby swing seat.  
 This equipment must be assembled and checked by an adult. Two adults may be required to assemble this product. Adult supervision is required at all times.  
 Before use please check all bolts are tight, secure and intact.  
 Check all coverings for bolts and sharp edges and replace when required.  
 Check swing seats, chain, ropes and other means of attachments relevant to your product for evidence of deterioration. Replace when required in accordance with the manufacturers instructions if necessary.  
 Place the product on level surface at least 2 metres from any structure or obstruction such as a fence, garage, house wall, overhanging branches, laundry line or electrical wires.  
 The items **MUST** be anchored firmly into the ground.  
**DO NOT** install the product over concrete, asphalt or any hard surface.  
**DO NOT** orientate the product directly towards the sun.  
 Leave all fittings finger tight until assembly is complete, for ease of construction. Then tighten firmly.  
 Children should not wear cycle helmets whilst on this equipment.  
 Do not allow children to stand on any swing seats, glider seats or slide chutes relevant to your product.  
 Do not allow the children to jump or climb off any moving equipment.  
 Do not twist swing ropes or wrap them over the top bar.  
 Do not allow loose, hooded or baggy clothes to be worn as children can get trapped and may be unable to free themselves.  
 Do not allow children to climb on parts of this equipment not intended for this purpose.  
 Do not allow children to wonder into the play area whilst the equipment is in use.  
 Gliders and swings must not exceed an angle of 60 degrees from the ground.  
 Regularly check the item for wear and damage, removing the item from use when necessary until replacement parts are fitted.  
 Failure to assemble and maintain this item as per instruction may cause injury to the user.  
 Please keep the instructions in a safe place for future reference.  
 The minimum clearance between the junior swing seat and ground level should be 350mm, the baby seat and ground should be 200mm.  
 Please contact our customer services department if you have any problems.  
 Inspect all parts of this product every 6 months following purchase. If any parts look worn or you find any problems, please contact us for replacements and do not use product until problem has been corrected. Hedstrom recommends replacing the plastic swing rope clamps every 2 years even if there is no sign of deterioration.  
 Do not modify this item  
 Conforms to EN71  
 Made in China to European Standards

## SWING PARTS LIST



**IMPORTANT: Make sure you read the safety notice on the front page and always supervise children while they are playing on the equipment. Once assembly is completed carefully check equipment. In the unlikely event that you do find any problems, please contact us. Do not allow children to use this product until the problem has been corrected.**

**STEP 1**  
Toddler Seat with T-Bar (for Children 6-36 Months)




**WARNING: DO NOT LEAN OR PUSH ON THE T-BAR.**

**THE CHILD MUST BE SECURELY FASTENED TO THE SEAT WITH THE HARNESS IMMEDIATELY TO AVOID INJURY**


1. Place the seat on the floor
2. The circle hole on the seat is for the backrest. The square hole on the seat is for the T-bar
3. Align the 3 connection points of the backrest/T-bar with that of the seat
4. Push the backrest/T-bar all the way down into the hole. (remark: it may be a bit tight. Assist with the body weight)
5. Tighten with the plastic bolt.

**WARNING: DO NOT OVER TIGHTEN PLASTIC BOLTS**

**STEP 2**  
Frame & Swing Assembly



**STEP 3**  
Frame & Swing Assembly




**NOTE:**  
Should the rope come off the rope/swing bearing during use please replace back on top of the rope/swing bearing.

**STEP 4**  
Fasten the seat harness attached to the seat

**TAKE CARE WHEN SEATING YOUR CHILD!**  
**THE CHILD MUST BE SECURED TO THE SEAT IMMEDIATELY TO AVOID ANY INJURY.**

To fasten push left and right hand side clips until they click into place.




To adjust the harness length, shift the buckle up/down.

**WARNING: HARNESS MUST BE FASTENED SECURELY AT ALL TIMES DURING USE IN THE TODDLER SEAT.**  
**WARNING: THE CHILD MUST BE SECURELY FASTENED TO THE SEAT WITH THE HARNESS IMMEDIATELY TO AVOID INJURY.**

### STEP 5

Toddler Seat without T-Bar (for children 6-36 months)



**THE CHILD MUST BE SECURELY FASTENED TO THE SEAT WITH THE HARNESS IMMEDIATELY TO AVOID INJURY**

#### TO REMOVE THE T-BAR

1. Press the seat base around the plastic bolt down.
2. Then unscrew the plastic bolt.

#### TO ATTACH THE CROTCH HARNESS


1. Place the crotch harness into the square hole and tighten with the bolt.

### STEP 6

Fasten the seat harness with crotch harness

**TAKE CARE WHEN SEATING YOUR CHILD!  
THE CHILD MUST BE SECURED TO THE SEAT IMMEDIATELY TO AVOID ANY INJURY.**


Remove buckle, please keep in a safe place so you can convert the swing again.




**WARNING: HARNESS MUST BE FASTENED SECURELY AT ALL TIMES DURING USE IN THE TODDLER SEAT**

### STEP 7

Junior Swing Seat (for Children 3-10 years)







### PLACING YOUR CHILD INTO THE SWING SAFELY



**STEP 8**  
Anchoring the swing to the ground

**IMPORTANT:** For safety reasons the swing **MUST** be anchored into the ground and concreted. If you are uncertain about this procedure telephone our helpline number.



MV Sports & Leisure Ltd.  
35 Tameside Drive  
Castle Bromwich  
Birmingham B35 7AG  
United Kingdom

**CUSTOMER SERVICES**  
MV has taken great care to ensure that this item has reached you in good condition. Should you have a query, please contact [customer.services@mvsports.com](mailto:customer.services@mvsports.com) where your query will be dealt with promptly. Alternatively, you can call on 0121 748 8017.



This mark denotes compliance with the standards laid down by the E.C. (European Community). It is your best interest to keep a note of our name and address for future reference. If you have any complaints or find this product to be faulty, in order to avoid any delay, please contact the distributor at the address above.

**Vulcan Consulting**  
EU Authorised Representative, The Merriion Buildings - Iconic offices, 18-20 Merrion Street, Dublin 2, D02 XH96, Ireland.