




This scooter is to be assembled by an adult
Please remove all packaging before giving to a child

In-line Scooter



FRAME

1. Pull the clamp lever over to release the tension on the locking mechanism
2. Use the locking mechanism slide lever to pull the sprung loaded locking mechanism out of the closed position slot.
3. Swing the steering column away from the foot plate until the locking mechanism clicks into open position slot.
4. Pull the clamp lever back to secure the locking mechanism in position



HANDLEBAR EXTENSION TUBE

1. Release the locking lever.
2. Push in location nipple and slide the tube up or down until it locates into the appropriate height position hole.
3. Push the clamp lever into the locked position
4. Ensure that the clamp holds the extension tube firmly in position. If not, release the clamp, tighten clamp adjusting screw and reclamp the extension tube.

SAFETY ADVICE:

This is a two wheel self propelled scooter designed for a single rider only.
It is not intended or equipped for road use, off road use, racing, jumping, stunt riding or use with any motorised device.

NOTE :

It should never be ridden by more than one person at a time. Never ride at night, obey all traffic and pedestrian regulations, and give right of way to pedestrians.

Care should be taken when riding on wet pavements as braking action and wheel traction may be reduced.
Never leave your scooter unlocked and unattended.

FOR YOUR CHILDS SAFETY :

Recheck that all screws, nuts and bolts are firmly tightened. Make sure that your child is capable of riding this scooter. Do not allow your child to ride unsupervised.

SCOPE AND LIMITED WARRANTY

This warranty does not cover damage or loss from accidents, normal wear, improper assembly or adjustment, jumping, stunt riding, racing or competition, abuse, neglect or when used with any motorised device.

Design and colour may vary from those illustrated. Please retain this leaflet for reference to the manufacturer. Carefully made in China to European Safety Standards.



MV SPORTS & LEISURE Ltd
35 Tameside Drive
Castle Bromwich • Birmingham
B35 7AG • UK

www.mvsports.com




The CE mark denotes compliance with the standards laid down by the EC (European Community).

HANDLEBAR

The procedure is the same for both handles

1. Push in the locating nipple on the handle.
2. Push the handle into the steering head until the nipple clicks into its locating hole.



ASSEMBLED SCOOTER

SAFETY FIRST

Please check all fixings are secure before handing to a child.


Ensure all locking devices are engaged.

WARNING: Protective equipment should be worn. Not to be used in traffic. 50 kg max.

MV recommends the use of protective pads and helmet when using this product.

The toy shall be used with caution, since it requires great skill, so as to avoid falls or collisions causing injury to the user and third parties.

Not suitable for children under 3 years. Small part. Choking hazard.



A GUIDE TO SAFE SCOOTERING

1. We recommend this scooter is for pavement use only. It is dangerous to ride on public highway.
2. Do not ride at night. Visibility is often limited at dawn and dusk.
3. Always give pedestrians right-of-way, and don't ride too close to them. Never park your scooter where it can cause a nuisance
4. Avoid hazards that may cause you to lose control of your scooter such as pot holes, uneven pavements and manhole covers.
5. Leave plenty of room when passing parked vehicles and watch out for doors being opened in your path.
6. Remember that braking distance should be increased in wet weather, and regular checks of brakes, steering and lighting should be made.
7. Never carry passengers on your scooter. Never carry packages in your hands while riding, or fix anything to your scooter that could obstruct your visibility or control.
8. Don't wear anything that restricts your hearing.
9. Always ride with both hands on the handlebars.
10. Don't wear very loose clothing, which could hang down and become caught in the wheels. Wear cuff bands or trouser clips to keep your trousers from getting caught in the chainwheel.
11. We recommend that light-coloured or fluorescent clothing be worn which helps others to see you in daylight and poor light.
12. Always wear proper safety equipment. We recommend a helmet, long-sleeved shirt, long trousers, shoes, elbow pads and knee pads. Gloves and eye protection also make good sense. Cover your handlebars, stem and top tube with safety pads for extra protection.

CUSTOMER HELPLINE

We make every effort to ensure that this product reaches you in satisfactory condition. However if you have any queries, need assistance, or find this product defective, please contact our Customer Helpline customer.services@mvsports.com. Alternatively, you can call on 08708404255.